

Date	Inspected by	Pressure kPa	Weight kg	Physical Condition

FASTEN TAG TO EXTINGUISHER BEFORE MOUNTING UNIT
DO NOT REMOVE THIS TAG : INSPECTION RECORD

Inspection & Maintenance

To ensure your Fire Extinguisher will be ready when needed.

- Read and follow the instructions on this Warranty Card.
- Inspect the Fire Extinguisher AT LEAST once a month.
- To ensure satisfactory operation, the pressure indicator MUST READ 1000kPa (10 fire extinguisher). If the indicator pointer is NOT in the green section of the gauge, then it is NOT to be used and should be recharged or replaced.
- Be sure the Safety Lock Pin is firmly in place.
- Keep the Fire Extinguisher out of direct sunlight at all times. Check for dents, scratches, corrosion or any other damage, and also check the Discharge Nozzle. Make sure the Discharge Nozzle is clean and free of obstructions.

DO NOT TEST BY PARTIALLY DISCHARGING. LOSS OF PRESSURE WILL OCCUR

FX FIRE SAFETY For warranty service please contact

Email: sales@fxfire.co.uk

FX FIRE SAFETY
FIRE EXTINGUISHERS

Warranty Details & Instructions For Use



WARRANTY INSTRUCTIONS

5 Year Limited Warranty

FX warrants to the original purchaser each new fire extinguisher to be free from defects in material and workmanship under normal use and services for a period of 5 years from the date of manufacture. FX agrees to repair or replace, at its option, any defective fire extinguisher provided that it is returned with postage prepaid and with proof of the purchase date to FX Fire's local FireBox agent.

This warranty does not cover damage resulting from accidents, misuse or abuse or lack of reasonable care of the product.

To the extent permitted by law, the liability of FX arising from the sale of this fire extinguisher or under the terms of this limited warranty, shall not in any case exceed the cost of a replacement fire extinguisher and subject to this clause, in no case shall FX be liable for consequential loss or damages resulting from the failure of the fire extinguisher or breach of this, or any other warranty, express or implied, loss or damage caused by failure to abide by the instructions supplied on this warranty card. This warranty is an addition to and does not exclude the rights of consumers under the Australian Trade Practices Act 1974, or any other law which may not be excluded.

HOW TO USE YOUR



FIRE EXTINGUISHER

Study the nameplate instructions and unit carefully to familiarise yourself with the operating instructions. FX portable fire extinguishers operate by squeezing the lever.


Each time the lever opens the valve, the stored pressure will force out some of the extinguishing agent. If the lever is not released the entire contents will be discharged.

Should a fire occur, grasp the fire extinguisher firmly and pull out the locking pin.



Hold the fire extinguisher upright and point the nozzle toward the base of the flames.

Remain low, out of smoke and heat; approach the fire as shown on the nameplate pictographs.



Squeeze the handle and lever and sweep the agent across the base of the fire in a side to side motion.



After the initial assault move progressively closer to the fire, enabling the powder to reach the furthest burning sections. Keep your back toward the wind. If the fire extinguisher discharge scatters the fire you are too close, move back until scattering action ceases.

After the fire is out, survey the area for several minutes for "flashback" or small recurrences or flame. Where there is smoke there can be fire. Be sure the fire is out. Clean up the area immediately after the fire is confirmed to be out. Some dry chemical agents may corrode property if not cleaned up soon after extinguishment. Shut off the power if you suspect the fire was of electrical origin.

WHICH FIRE EXTINGUISHER SHOULD YOU USE?

There are two common types of fire extinguishers.

- Type AB(E) fire extinguishers fight wood, paper & textile fires, plus flammable liquids & electrical fires.
- Type B(E) fire extinguishers are for flammable liquids & electrical fires.

To determine which class or classes of fire the fire extinguisher is designed to fight, read the fire extinguisher label.

Be sure you understand which fire extinguisher is appropriate for each class of fire. For protection against ALL common classes of fires, you must choose a type AB(E) fire extinguisher.



Avoid inhaling the dry chemical agent. The agent contained in this fire extinguisher is not toxic, but may cause skin irritation.

In case of contact, flush the affected area with clean, cool water. If irritation persists, contact a doctor immediately.



SERVICE & INSPECTION RECORD TAG

Model No: _____

MFG Date & Batch No: _____ / _____ / _____

Month Year Batch No.
The (MFG) manufacturing date and Batch Number are shown on the lower skirt of the fire extinguisher in the above sequence.

REPLACE OR RECHARGE IMMEDIATELY AFTER USE

Customer Service :
Email: sales@fxfire.co.uk

A metal Inspection and Maintenance tag is provided for fire extinguisher installations that need servicing in accordance with Australian Standard 1851 and OH&S requirements.